



INSTRUCTIONS:

- Thread pitch: M15x0.75; will fit only the M-305.
- Front sight assembly needs to be removed. You will not be able to use iron sights. An optics mount is required.
- It is recommended to use Loctite 262 (Red) on the set screw to prevent it from becoming loose while firing.
- Thread the brake on until it stops, and rotate it back until the top ports are vertical. Then install the supplied set screw using Loctite 262 (Red).

