

**Thank you for the purchase of the
Matador Arms aluminum SKS
Extended Magazine Release.**



INSTALLATION INSTRUCTIONS

Important!!!

Please ensure your rifle is unloaded prior to starting any work.

Place your ammunition away from the workspace.

1. Remove the trigger assembly from the rifle; remember to have the safety on.
2. Pull a small amount of tension rearward on the original magazine release, and push the cross-pin out. If it will not slide out easy, use a small punch.
3. If you drive the pin out, make sure to keep tension on the release, otherwise the spring will fly out.
4. Install the Matador Extended Magazine Release using the factory spring and pin.
5. If any resistance is found with the Matador release, use a small file to smooth out the rails and add a small amount of gun oil.

Have questions or comments? Or, interested in our other products? CONTACT US!

www.matadorarms.com

info@matadorarms.com

587.225.3689

