

Thank you for the purchase of the Matador Arms SIDEWINDER.



INSTALLATION INSTRUCTIONS

Important!!!

Please ensure your rifle is unloaded prior to starting any work.

Place your ammunition away from the workspace.

INFO

The Sidewinder is designed to work with any AR-style buffer tube thread. In order to determine if it will work on your firearms, you need to have a female buffer tube thread.

The folding adapter is solid and will not allow a buffer to pass, and as such, will not work on an actual AR-15.

The Sidewinder will fold both to the left and right side of the rifle. As it will fit a multitude of firearms and buttstocks, we are not able to give specific instructions per each different configuration.

Factors to consider are:

- Charging handles
- Possibility of covering the ejection port

OPERATION

Push the lock button on the side of the adapter to unlock and fold the stock. To unfold the stock, press the top of the pin while simultaneously unfolding the stock to the open position.



INSTALLATION



1. Open the adapter and slightly loosen the two screws on the inside with one full turn on each screw, using the supplied hex key.
2. Thread the male end into your rifle (into the female thread).
3. Position the Sidewinder to fold left or right, as you prefer.

4. Tighten the two screws to prevent the adapter from turning.

Note: If you have the screws too loose, repeat Step 1, but only try ½ a turn on each screw.



**Have questions or comments? Or, interested in our other products?
CONTACT US!**

www.matadorarms.com

info@matadorarms.com