

Thank you for the purchase of the Matador Arms



INSTALLATION INSTRUCTIONS

Important!!!

Please ensure your rifle is unloaded prior to starting any work.

Place your ammunition away from the workspace.

INFO

- The Mag-X will only work in milspec AR-15 lower receivers. Lower receivers with a non-standard magwell will not work with the Mag-X.
- Must use a 9mm Glock-Cut Bolt. The standard 9mm bolt from an AR-15 that uses UZI or Colt SMG magazines will not work. Any 9mm Glock-Cut Bolt will work.
- Requires a 9mm AR-15 Upper.
- A heavier 5.8oz buffer is recommended for reliable operation.
- The Mag-X does not have a last round bolt hold open (LRBO).

INSTALLATION

1. With the Mag-X out of the package, insert your pistol magazine in it and make sure it latches. Remove the magazine from the adapter.
2. Insert the adapter into the magazine well of the lower receiver. Press the magazine release on the lower receiver as you insert the adapter into the magazine well.
3. Once inserted, check that the magazine release on the lower receiver keeps the Mag-X in place.
4. As tolerances in AR-15 magazine wells can be different, the Mag-X may be a very snug fit or very loose.
5. Install the bolt on the top of the Mag-X with the nylon washer to lock the Mag-X into the lower receiver. This prevents accidentally dropping the mag adapter if you press the magazine release on the lower.



Have questions or comments? Or, interested in our other products? CONTACT US!

www.matadorarms.com / info@matadorarms.com